

Liste exhaustive des télécommandes compatibles

AZ REMOTE - TÉLÉCOMMANDE UNIVERSELLE 433.92 MHZ

SANS ROLLING CODE

<i>Marque</i>	<i>Modèle</i>
ADYX	ALIZE EM2C, ALIZE EM4C
AETERNA	TX433 1,2,4 buttons
ALLMATIC	AEMX1, AEMX2, AEMX4
	EUROPE AUTO ARMY2, ARMY1, AR MY 4
	MX1, MX2, MX4
ALLTRONIK	S429_1,S429_2, S429_4, S429_M Be sure that your remote operates at 433.92MHz!
	S425
ANSONIC	SA 434-1 E, SA434-2E, SA434- 3E, SA434-4E
	SA 434-1 MINI, SA434-2MINI, SA 434-2Midi
APERTO	CPS 1, CPS2, CPS4
AVIDSEN	100601 micromark MM23164
	104505
	100951,100955, 100550, 100400
BELFOX	DHS433-1, DHS433-2, DHS433- 4, dip switch version
	DHS 433,92 (7733), dip switch version

BENINCA'	LOT1W, LOT2W, LOT4W
	LOT2WMS
	T2WK, T4WK
	LOTX1 W, LOTX2W, LOTX4W
	TO.G02WP, TO.G04WP, TO.G02WK, TO.G04WK
BESIDE	BEZAP
	HIT
BFT	TE01, TE02 (TE01, TE02)
	TE04 (TE04)
CAME	T432, T434, TOP432A, TOP434A, TOP432, TOP432NA, TOP434NA
	TOP432M, TOP434M
	TAM432SA
	TOP432SA
	TOP432NA
	TWIN2, TWIN4
CARDIN	S476 TX2, S476TX4
CASA LI GENIUS	Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433
CASIT	ERTS92B, ERTS92T
	ERTS200B,ERTS200Q
	ERTS4760,ERTS476Q
	TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T
CELINSA	S10 1, S10 2, SAW1, SAW2
CENTURION	CLASSIC, SMART, SMART2
CPS	TCP3, CPS, Jolly 4
	CPS 1 TCP3, CPS2 TCP3, CPS4 TCP3 EM1CV, EM2CV, EM4CV
DASPI	Happy2, Pops2Â,

DEA	4331,4332,4334
	Genie
	Punto S2
	Oea MIO T02, MIO T04
DELMA	Mizard 433 1, Mizard 433 2
	King 433 2
	Style Copy 2CH (this is a code duplicator)
DICKERT	MAHS433 01, MAHS433 04
	S10-433A1LOO, S10-433A4LOO, S20-433A 1 LOO, S20-433A4LOO, S20-433A 1000, S20-433A4000
	S5-433-A2LOO, S5U-433-A2LOO
DITEC	PANDIS, and it works with ail the DITEC receivers.
	BIX LS2, BIX LP2, BIX
DOITRAND FDOITRAN	MPSTF2E JAUNE, MPSTF4E, HYPERPHONE MPSTF2E GRISE
	TS2DE,TS4DE
DOORMATIC	SAW
DUCATI ALLDUCKS	TSAW1, TSAW2, TSAW3, TSAW4, 124 ELBER TSAW1, TSAW2, TSAW3, TSAW4 RONDY TSAW1, RONDY TSAW2, RONDY TSAW3
	TPR10-A, TPR20-A RONDY TPR10 A, RONDY TPR20 A
	TE2
	HC6203, 6203: only blue , red and transparent
ELBE	501,502,504
	502a,504a
	502,504
ELCA	IRIS, IRIS 9CH. Both colors red and blue
	ASTER2
	Aster 1000, Aster1 001. Colors: black, blue, light Qrey
	GEMINI9CH
	VIRGO

ELVOX	
	ET03,ET04
ERONE	SETDS39433E2, SETDS39433E4
FAAC	TM1 433 OS, TM2 433 OS, TM3 433 OS
	TML2 433 SLP, TML4 433 SLP, TML2-433-SLP, TML4-433-SLP
FADINI BPT	433 2M, Astro43_2m
	Astro433-2, Astro433-4, Astro43-2, Astro43-4
FERPORT	Tac1, Tac2, Tac4, Tac1 k, Tac2k, T ac4k, T ac2kr
GIBIDI	Open TMB 433, OPEN TMQ 433, OPEN OUT 2, OPEN OUT 4
GULLIVER	MOW2E
HAUss	Pocket 3750-1, Pocket3750-2, Pocket 3750-4
HRC	
JAY	UBEI x1 SL 1
	UBET 11, UBET 21, UBET 31, UBET 41, UBET 61, UBET 61A,
IUPPITER	RJW/1 E, RJW/2E, RJW/4E, RJW/12E
	MOW/1 E, MOW/2E
LEB	TMW
	TSAW2N, TSAW4N
	TCP3A, (this is a code duplicator)
	TRK4 Note: receiver should be configured to disable rolling check.
	TPW4
LINCE	LR 2035

MA SYSTEM	MA TX1, MA TX2, MA TX3
MARANTEC	0101
	012
	0212,0222,0232
	Digital 302, 0302
	Digital 304, 0304
MEIÄfA"NER MEISSNE R	LW433-1, LW433-2, LW433-4
	Pocket 3750 1,2,4
MONSEIGNEUR	ARC2, ARC4
	TOR 4003845, TOR 4003846, TOR 400 3847 T1 SAW433, T2SAW433, T4SAW433
MOTORLINE STATEUR OP	MX1, MX2, MX3, MX4, MX6
	MX11, MX12, MX13
MOTOSTAR	CLiKSTAR2, CLiCKSTAR4
	CLiCK-4M, CLiCKSTAR RE 532, CLiCKST AR RE 534
NICE	EASY S1, S2, S4
	FL01, FL02, FL04
	VERYVE
NOLOGO	ECO OIP
OG	OG62,OG64
OPENOUT	TMQ 433 2, TMQ 433 4
PIAZZETTA	4 buttons for wood/pellet heater
PORTAMATIC	MPH01, MPH02
POWERFIX Profi (Lidl)	RCB-A 3600R
PROEM	ER2C4ACM,ER4C4ACM

PROGET	ETY 433N2, ETY 433N4
	EM1433-N2
PROTECO	TX433
	EUROMATIC
	HIT
QUASAR	433 TANGO SLIM BLEU
SEA	SMART433_TX2_OIP, SMART433 TX3 OIP SMART4 33_TX2_COPY,SMART433_TX 3_COPY Smart2 Dip Switch, Smart3 Dip Switch
SEAV	TXS1, TXS2, TXS3, TXS4
	Behappy S1, Behappy S2, Behappy S3
	Be Easy TX, Be Easy Murale2
	BeSmart S2, BeSmart S4
	BeFree S1
SECURVERA	SVR2C
	SVR2C
	SVR4C
	SVR6C
SEN DER	
SERAI	OG/52, OG/54, OG/82, OG/84
	OG/28, OG/48, OG/62, OG/64
	OG/02,OG/04
SICE	TX4 CLACK Bigfoot
SIMINOR	ER2C4ACM, ER4C4ACM, ER2C4ACS,ER4C4ACS
SMD	LW433-1, LW433-2, LW433-4 :

	AM models only
SOMFY	LEB TMW
STAGNOLI	ZEUS AZTR
STARTEC	TXQ2
TAU	250 SLIM
	250TXD2, 250TXD4
	250BUG2, 250BUG4
TECNOMATIC	TQ433
TEDSEN	SKX1 MD, SKX2MD, SKX3MD, SKX4MD
BERNER	SKX1KD, SKX2KD, SKX4KD, SKX6KD
GFA	SKX1 DL, SKX2DL, SKX3DL, 33_ TX2_COPY, SMART433_ TX 3_COPY Smart2 Dip Switch, Smart3 Dip Switch