

Vitamix Three Speed Blender

To clean:

1. Fill the container half full with warm water and add a couple drops of liquid dish washing detergent to the container.
2. Snap or push the complete 2-Part lid into locked position.
3. Set the Speed Control Dial to Low. Turn blender on and use the Speed Control Dial to increase to High.
4. Run the blender on High for 30 to 60 seconds.
5. Turn off the blender, and rinse and drain the container.

To sanitize:

1. Follow Normal Cleaning instructions above.
2. Fill the container half full with water and 1 ½ teaspoons of liquid bleach.
3. Snap or push the complete 2-Part lid into locked position.
4. Set the Speed Control Dial to Low. Turn blender on and use the Speed Control Dial to increase to High.
5. Run the blender on High speed for 30 to 60 seconds.
6. Turn off the blender, and allow mixture to stand in the container for an additional 1 ½ minutes.
7. Pour bleach mixture out. Allow container to air dry.
8. Do not rinse after sanitizing.